



ROUGH WALL OPENINGS AND PLACEMENT FOR B3474 AND B3574



ROUGH OPENING
16" W x 29 1/4" H

ELEVATION
Start Rough Opening
13 3/4" Off the Finished Floor




LEFT SIDE UNIT
B3574 OR B3474


RIGHT SIDE UNIT
B3574 OR B3474

ROUGH WALL OPENINGS AND PLACEMENT FOR BRADLEY 5912 AND 5922

ROUGH OPENING
15 3/8" W x 28 7/8" H



ELEVATION
Start Rough Opening
15 5/8" Off the Finished Floor




LEFT SIDE UNIT
BRADLEY 5912 OR 5922

RIGHT SIDE UNIT
BRADLEY 5912 OR 5922

ROUGH WALL OPENINGS AND PLACEMENT FOR ASI 0482 AND 0485


ROUGH OPENING

15 3/4 x 29



ELEVATION

Start Rough Opening
14" Off the Finished Floor



LEFT SIDE UNIT

ASI 0482 OR 0485

RIGHT SIDE UNIT

ASI 0482 OR 0485